





## 05222000 - LT-S VDI40 ER32 H97 DIN5480 SA

|                              |                                                                                                                                                                           |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Type</b>                  | LT-S<br>Tool holder straight                                                                                                                                              |
| <b>Mounting</b>              | VDI 40                                                                                                                                                                    |
| <b>Tool output</b>           | Collet nut ER 32                                                                                                                                                          |
| <b>Coolant</b>               | External coolant                                                                                                                                                          |
| <b>Direction of rotation</b> | r1  r2  |
| <b>Max speed [rpm]</b>       | 6000                                                                                                                                                                      |
| <b>Max torque [Nm]</b>       | 40                                                                                                                                                                        |
| <b>Ratio</b>                 | 1:1                                                                                                                                                                       |
| <b>H [mm]</b>                | 97                                                                                                                                                                        |
| <b>Accessories</b>           |                                                                                                                                                                           |
| <b>Notes</b>                 | N.A.                                                                                                                                                                      |
| <b>Mounting tips</b>         | Not suitable for every application, please check                                                                                                                          |



**ATTENZIONE: VERIFICARE L'ORIENTAMENTO DELLA DENTATURA VDI**

Always check live tool dimensions on the turret



|          |            |               |
|----------|------------|---------------|
| DATE/ATA | 12/12/2015 | 05222000-R011 |
|----------|------------|---------------|

Subject to technical changes